

Accessories for JUKI household sewing machines



Household
sewing machine



1-Needle lockstitch
sewing machine



Home sergers



Contents are subject to change without notice.

JUKI


JUKI CORPORATION

2-11-1, TSURUMAKI, TAMA-SHI, TOKYO
206-8551, JAPAN

<http://www.juki.co.jp>

JUKI CORPORATION holds the rights to change technical specifications without prior notice.

As of May 2014



1405(B)

Household sewing machine



1 Standard Presser Foot
For straight stitch and zigzag stitches



2 Overcasting Presser Foot
It prevents the edge of fabric from fraying



3 Buttonhole Presser Foot
For automatic buttonholes



4 Manual BH Presser Foot (Decorate Stitch Presser Foot)
For decorative stitches, letters and manual buttonholes



5 Zig Zag Presser Foot
For decorative stitches or letters



6 Button Attaching Presser Foot
For attaching buttons on garments



7 Zipper Presser Foot
For attaching zippers



8 Invisible Zipper Foot
For installation of concealed zipper



9 Blind Stitch Presser Foot
For blind hem stitching



10 Smooth Presser Foot
For hard-to-feed fabrics (vinyl cloth, leather)



11 Roller Foot
For hard-to-feed fabrics (vinyl cloth, leather, toweling)



12 Rolled Hemming Presser Foot
For hemming stitch with rolled fabric (3mm)



13 Hemming Presser Foot for Zigzag
For hemming zigzag stitch with rolled fabric



14 Straight Stitch Presser Foot
For straight stitch sewing



15 Walking Foot
It prevents sewing slippage of fabric such as velvet and quilting



16 Binder Presser Foot
For attaching bias tape into for folds



17 Patchwork Presser Foot
For patchwork stitches with 1/4 inch and 1/8 inch guide



18 Presser Foot with Guide
Presser foot with 2mm distance guide



19 Edge Sewing Presser Foot
For patchwork sewing (Sewing center line of joined materials by using the center guide)



20 Quilt Presser Foot
For quilting or free-motion embroidery



21 Quilt Presser Foot (open type)
For free motion sewing. (Front part is open for better visibility)



22 Quilt Presser Foot (transparent type)
For free motion sewing and zigzag free motion sewing



23 Open Toe Presser Foot
For applique and decorative stitch. (Front part is open for better visibility)



24 Applique Presser Foot
For applique stitch (Front and back parts are short for easy movement at curve points)



25 Pearl Attaching Presser Foot
For attaching pearls, beads and thick cord



26 Cording and Embroidery Presser Foot
For free motion quilting together with cord sewing



27 Cording Presser Foot (for 3 cords)
For attaching three or less cords as decorative stitch



28 Gathering Foot



29 Quilt Guide



30 Auxiliary Spool pin



31 Throat Plate for Straight Stitch




32 Wide Table



33 Bobbin


1-Needle lockstitch sewing machine



1 Standard Presser Foot
For regular sewing



2 Zipper Attaching Foot
Foot position can be moved to right or left




3 Solid Cording Foot (Right/Left)
For edge sewing and fastener attaching



4 Hinged Cording Foot
Suitable for edge sewing and overlapped seam



5 Hinged Zipper Foot
Narrow width of foot feeds zipper smoothly



6 Invisible Zipper Foot
For installation of concealed zipper




7 Smooth Foot
For hard-to-feed fabrics such as vinyl cloth, leather



8 Hemming Foot
For hemming stitch with rolled fabric (3mm)




9 Piping Foot
To attach corded piping



10 Compensating Foot (Right/Left 1.5mm)
For sewing side of overlapped seam (1.5mm)



11 Compensating Foot (Right 7.0mm)
To sew 7.0mm from overlapped seam



12 Regular Hinged Foot (6.5mm) (7.5/7.0mm)
The foot edge guides 6.5mm or left 7.5mm/right 7.0mm from needle



13 Even Feed Foot
It prevents sewing slippage of fabric such as velvet and quilting



14 1/5" Quilting Foot
For regular free motion



15 1/4" Quilting Foot
Suitable for sewing equally spaced curved lines



16 T Gauge
To guide edge of fabrics (set by 2 screws)



17 Swing Gauge
To guide edge of fabrics (set by 2 screws)



18 Magnetic Gauge
To guide edge of fabrics



19 Foot & Throat Plate for Thin Fabric
The small hole of foot and throat plate prevents material puckering



20 Throat Plate for Thick Fabric
The large hole of throat plate is suitable for thick needle



21 Bobbin



22 Bobbin Case

Home sergers



1 Standard Presser Foot
For regular sewing and attaching tapes



2 Blind Stitch Presser Foot (for Right Needle)
For making blind hems



3 Universal Blind Stitch Presser Foot (for Right & Left Needle)
For making right/left needle blind hems and flatlock



4 Elasticator Presser Foot
To attach elastic tape to stretch fabrics



5 Cording Presser Foot
For attaching nylon string or wire on edge of fabrics



6 Beading Presser Foot
For attaching pearls and beading with overlock stitching



7 Curved Beading Presser Foot
For attaching pearls and beading on a curve



8 Piping Presser Foot
For sewing piping



9 Gathering Presser Foot
For gathering and sewing with differential feed



10 Taping Foot
For attaching tapes



11 Coverstitch Hem Guide
For guiding folded hems for perfectly placed coverstitching

Household sewing machine attachment list

		HZL-F series	HZL-G series	HZL-K series	HZL-350Z series	HZL-27Z/29Z	HZL-12Z
1	Standard Presser Foot	40057923		40051131	40151600	40051131	40130228
2	Overcasting Presser Foot	40080960	40110163	40117901	40145869	40050948	
3	Buttonhole Presser Foot	40080966	40110162	40117900	40151623	40088436	
4	Manual BH Presser Foot (Decorete Stitch Presser Foot)	A9828-008-0A0	40112905	40130234	40145868		
5	Zig Zag Presser Foot			40117722			
6	Button Attaching Presser Foot	40080969		40116156	40151630		
7	Zipper Presser Foot	A9823-010-0A0		40117903	40151622	40050946	40152343
8	Invisible Zipper Foot	40080955		40117861			
9	Blind Stitch Presser Foot	40080961	40112904	40117902	40145872	40050947	
10	Smooth Presser Foot	40079312					
11	Roller Foot			40117711			
12	Rolled Hemming Presser Foot	40080958		40117710	40145870		40141258
13	Hemming Presser Foot for Zigzag	40080957					
14	Straight Stitch Presser Foot			40116154	40145874		
15	Walking Foot	40080963		40117721	40145876		
16	Binder Presser Foot	40080954					
17	Patchwork Presser Foot	40080959		40117712		40089759	
18	Presser Foot with Guide	40080952					
19	Edge Sewing Presser Foot	40080965					
20	Quilt Presser Foot	40080964		40052013	40145873		
21	Quilt Presser Foot (open type)	40080949					
22	Quilt Presser Foot (transparent type)	40080953					
23	Open Toe Presser Foot	40080962					
24	Applique Presser Foot	40080951					
25	Pearl Attaching Presser Foot	40080956					
26	Cording and Embroidery Presser Foot	40080950					
27	Cording Presser Foot (for 3 cords)	A9829-880-0A0			40145871		
28	Gathering Foot				40145875		
29	Quilt Guide	A9833-550-0A0			40151624		
30	Auxiliary Spool Pin	40080967			40151633		
31	Throat Plate for Straight Stitch	40080968	40080968 & 40064685(hook cover)				
32	Wide Table	J-FT (J-F/Table)		J-ET (J-E/Table)			
33	Bobbin	001141000000		A9834-030-0A0	40151627	A9834-030-0A0	40130125

HZL attachment Set for HZL-F/G series
Advanced Quilter's Kit (19 21 22 23 24 25): 40091174
Heavy User Kit (6 8 12 16 18 26): 40091175
Creative Set (18 23 24 25 26 27 33 x5): 40108163

1-Needle lockstitch sewing machine attachment list

1	Standard Presser Foot	A9836-D25-0A0	11	Compensating Foot (Right 7.0mm)	A9850-D25-0A0
2	Zipper Attaching Foot	A9838-090-0A0	12	Regular Hinged Foot (6.5mm)	A9849-D25-AA0
3	Solid Cording Foot (Right)	A9844-D25-AA0	13	Regular Hinged Foot (7.5/7.0mm)	A9849-D25-BA0
	Solid Cording Foot (Left)	A9844-D25-BA0		Even Feed Foot	A9811-D25-0A0
4	Hinged Cording Foot	A9844-D25-CA0	14	1/5" Quilting Foot	A9811-E98-AA0A
5	Hinged Zipper Foot	A9842-D25-0A0	15	1/4" Quilting Foot	A9811-E98-BA0A
6	Invisible Zipper Foot (Metal)	A9841-D25-AA0	16	T Gauge	A9846-D25-0A0
	Invisible Zipper Foot (Plastic)	A9841-D25-BA0	17	Swing Gauge	A9847-D25-0A0
7	Smooth Foot	A9840-D25-0A0	18	Magnetic Gauge	A9848-D25-0A0
8	Hemming Foot	A9837-090-0A0	19	Foot for Thin Fabric	A9813-096-0A0A
9	Piping Foot	A9845-D25-0A0		Throat Plate for Thin Fabric	A9839-090-AA0
10	Compensating Foot (Right 1.5mm)	A9843-D25-AA0	20	Throat Plate for Thick Fabric	A9839-090-BA0
	Compensating Foot (Left 1.5mm)	A9843-D25-BA0	21	Bobbin	A9851-D25-0A0
			22	Bobbin Case	A9852-D25-0A0



Home sergers attachment list

		MO-1000	MO-735	MO-734DE MO-655 MO-654DE MO-644D	MO-623	MO-50e
1	Standard Presser Foot	40134861	A1501-130-0B0	Check JUKI website	A1501-613-0B0A	40131302
2	Blind Stitch Presser Foot (for Right Needle)	40138091	A9810-634-0A0A			
3	Universal Blind Stitch Presser Foot (for Right & Left Needle)	40149058	A9521-634-0A0A			40131946
4	Elasticator Presser Foot	40138095	A9815-655-0A0A			40131947
5	Cording Presser Foot	40138099	A9820-655-0A0A			
6	Beading Presser Foot	40138106	A9870-634-0A0A			40131949
7	Curved Beading Presser Foot	40149059	A9511-634-0A0A			
8	Piping Presser Foot	40138103	A9865-655-0A0A			40131950
9	Gathering Presser Foot	40138121	A9860-655-0A0C			40131948
10	Taping Foot					40131951
11	Coverstitch Hem Guide		40122229			

MO attachment Set for MO-1000
8pcs.(2 3 4 5 6 7 8 9): 40149062
6pcs.(2 4 5 6 8 9): 40149061
3pcs.(2 4 5): 40149060

MO attachment Set for MO-700/600series
8pcs.(2 3 4 5 6 7 8 9): 40123395
6pcs.(2 4 5 6 8 9): 40064938
3pcs.(2 4 5): 40064939

MO attachment Set for MO-50e
6pcs.(3 4 6 8 9 10): 40134119